



Extend the frame to full width, ensure all corners have locked in position (do not extend legs).



Remove the upper peak pole section.



Remove (4) Nuts and Bolts to release the lower peak pole section.



Place the spring on the lower Illumipeak section and insert through the upper bracket.



Fasten the Illumipeak housing using (4) provided nuts and bolts.



Release each corner brackets and partially close the frame. Now install the upper Illumipeak profile.